User Manual – KONNWEI KW310 CAN OBDII+EOBD Code Reader

Specifications

1. Ordered List Item 1) Display: Back lit, 128 x 64 pixel display with contrast adjustment
2. Operating Temperature: 0 to 60°C (32 to 140 FO)
3. Storage Temperature: -20 to 700C (-4 to 158 FO)
4. External Power: 8.0 to 18.0 V power provided via vehicle battery

Accessories Included

OBO U cable - Provides power to tool and communicates between tool and vehicle.

Selects the desired language:

English, French, German, Dutch, Spanish, Russian, Portuguese.

1.0 Generallnrormatio n: On-Board Diag nostics (OBOl n The first generation of On-Board Diagnostics (called OBO I) was developed by the California Air Resources Boord (ARB) and implemented in 1988 to monitor some of the emission control components on vchiclcs. As technology evolved and the desire to imp~ove the On-Board Diagnostic system increased, a new generation of On-Boord Diagnostic system was developed. This second generation of On-Board Diagnostic regulations is called ';080 U“. The OBD IJ system is designed to monitor emission control systems and key engine components by performing either continuous or periodic tests of specific components and vehic le conditions. When a problcm is detected. the OBD II system turns on a warning lamp (MIL) on the vehicle instrument panel to alert the driver typically by the phrase of “Check Engine” or “Service Engine Soon”. The system will also store important information about the detected malfunction so that a tcchnician can accurately find and fix the problem. Here below follow three pieces of such valuable information:

1. Ordered List Item Whether the Malfunction Indicator Light (MIL) is commanded 'on ' or ' off';
2. 2) Which, if any, Diagnostic Trouble Codes (DTCs) are stored;
3. 3) Readiness Monitor status.

1.1 Location of thc Data Link Connector (OLC) The DLC (Data Link Connector or Diagnostic Link Connector) i$ the standardized 16-cavity connector where diagnostic scan tools interface with the vehicle's on-board computer. The OLC is usually located 12 inches from the center of the instrument panel (dash), under or around the driver's side for most vehicles, IF Data Link Connector is not located under dashboard, a label should be there telling location, For some Asian and European vehicles, the OLe is located behind the ashtray and the ashtray must be removed to access the connect If the OLC cannot be found, refer to the vehicle's service manual for the location.

From:
https://installconfig.com/ - **Install Config Wiki**

Permanent link:
https://installconfig.com/doku.php?id=konnwei_kw310_can_obdii_eobd_code_reader&rev=1602358429

Last update: **2020/10/10 19:33**